

### Appropriate Pre-Cast Counter Thickness:

Press	Emboss/Deboss	Combo	Chase
Kluge	.030	.060	H, B
Heidelberg/Windmill	.030	.030	B
Heidelberg/Cylinder	.015	.015	H
Heidelberg/Goldboss	.030	.030	G
Steuer Foil Jet	.007	.007	H
Bobst	.060	.060	H
Thomson	.060	.060	H, B
Gietz	.060	.060	H
Iijima	.060	.060	H
C & P	.060	.030	H
Franklin	.060	.060	H, B, P
Wagner	.060	.060	B, P
Carver	.060	.060	P
Kensol	.060	.060	H, B, P
Saroglia	.060	.060	H, B
Consolidated	.060	.060	H, B
Acromark	.060	.060	H, B, P
Imperia	.060	.060	H, B

### Chase Abbreviations:

**H-** Honeycomb requiring toggle hook of 10 degree with a 30 degree undercut

**B-** Bunter Posts with holes 3/32" on 1" centers requiring 10 degree

**P-** Plain solid steel sheet requiring 10 degree or 90 degree

**G-** Goldboss unit requiring 1/8" step edge lip